





使用说明书



10. RS232C





直阻测量

历史数据

系统设置

帮助

2009-06-08
09:42:25



已读003条 剩余197条

编 号	测试时间
000	2009-07-17 10:12:07
001	2009-06-28 11:35:16
002	2009-05-17 15:45:18

↑ 清空 导出 返回

已读003条 剩余197条

编 号	测试时间
000	2009-07-17 10:12:07
001	2009-06-28 11:35:16
002	2009-05-17 15:45:18


↑ 清空 导出 返回



1

USB

setup.exe



2

“ ”



COM1

“ ”

COM1


”

“

”

“

”



“

”

	× ×	

2.

AC220V ± 10% 50Hz ± 10%
DC28V

3.

-20 50 ≤ 80%

4.

10A	1mΩ - 2Ω
5A	1mΩ - 4Ω
1A	100mΩ - 20Ω

±
μ Ω

- 1
- 2
- 3
- 4
- 5
- 6
- 7



Ω

50

	Ω

	Ω